Sterilizer Operations

‘*Left*’ and ‘*Right*’ are used as if you are sitting in drivers seat.

---

1. **Starting & Driving**
    1. Turn on battery disconnect switch
        - *Turn on battery disconnect switch*
    2. Turn on ‘Control Power’
        - *Switch will illuminate green. If it does not, make sure E-stop is not pushed in.*
    3. Start Engine using ‘Engine Start’
        1. The switch is like a normal key. Off-On-(Crank).
        2. If it does not start, do this: turn off, wait 1 sec, turn on, wait 1 sec, then start.
        3. If at any time the E-Stop is used, it will trigger an alarm on engine controller, and you will hear it beeping. The ‘Engine Start’ switch must be cycled Off-On-Off to reset the alarm.
    4. Press the Green ‘Low Speed mode’ button.
        - It is near center of operator panel, with a yellow button above it and red one below it.
        - It will illuminate green once pressed, and only after engine is running.
        - You cannot drive or steer before doing this.

Nurse Tank Operations

Click pictures for a full size image

1. Open both valves
    1. 

From:
https://www.wiki.brigadetek.com/ - **Peter's Wiki**

Permanent link:
https://www.wiki.brigadetek.com/public/gnc/operation_manual?rev=1660780963

Last update: **2022/08/17 20:02**